

## Gemini

Base cutting plate, Plastic shim, Magnetic positioning shim, die (cutting side up), cardstock, clear cutting plate

### Cut 'n' Boss

Platform D  
Platform B  
Platform A  
Magnetic shim  
Die (cutting side up)  
Cardstock  
Platform A

### eBoss

Platform D  
B shim  
Platform C  
Magnetic shim  
Die (cutting side up)  
Cardstock  
Platform A

### Big Shot

Multi Purpose Platform (all tabs)  
Cutting mat  
Die (cutting side up)  
Cardstock  
Cutting mat

### Evolution

13" platform  
Die (cutting side up)  
Cardstock  
Platform A

### Grand Calibur

Platform A  
Die (cutting side up)  
Cardstock  
Platform C

### Todo

Platform B  
Die (cutting side up)  
Cardstock  
Platform A

### Crossover

White cutting plate  
Die (cutting side up)  
Cardstock  
Clear cutting plate

### Cuttlebug

Platform A  
Platform C  
Die (cutting side up)  
Cardstock  
Platform B

### Joy Trevaile

Platform A (Base)  
Die (cutting side up)  
Cardstock  
Platform C (grey)

### Sizzix Big Kick

Multi Purpose Platform (all tabs)  
Die (cutting side up)  
Cardstock  
2 x big kick  
Cutting mats

### Sizzix Sidekick

Clear cutting plate  
2x Sizzix adaptor 2.5"x7.5" to cover the length of your plates  
Die (cutting side up)  
Cardstock  
Clear cutting plate

### Sizzix Vagabond

Platform  
Solo thing adaptor  
Cutting mat  
Die (cutting side up)  
Cardstock  
Cutting mat

## Evolution Advanced

To cut, turn your dial to the letterpress setting, or the lowest die-cutting setting, and configure your plates as follows:

Cutting & Embossing platform, Die (cutting side up), Card, Mat